

1. Power on **Express**. Dock recorder to top of **Express** with buttons/LCD facing up-make sure recorder is fully seated in **Express**. If an “Unable to Download” error message is displayed, remove recorder from dock and re-insert - static electricity can cause this message. **Select RF** and **Boomerang RF** are Radio Frequency (wireless) enabled --no need to hard dock. Data can be transmitted up to 300 feet line-of-sight.
2. Press “Receive/Download” button on **Express**. For RF SIGNAL- **HOLD** the button until devices are contacted and download is complete. Blinking red LED indicates out of range conditions were detected during the monitoring period. If desired, enter P.O. number and/or other information using keypad. Use Shift key to change from numeric to ALPHA (Caps) or alpha (lower case). *IMPORTANT: Press ENTER to save each entry*
3. Follow on-screen instructions to view chart/summary/details to evaluate all data.
4. View **Previous** record or move forward to **Next** record. A different recorder can be docked and downloaded at any time. Data is automatically saved in **Express** until the CLEAR ALL button is depressed or the data is downloaded to a PC. **Express** also displays battery level and the number of records in memory. Data from up to 100 recorders can be saved and downloaded at one time.

Power: **Express** can be recharged using the included A/C adaptor-Be sure to Power ON **Express** to charge. The mini USB plugs into the end opposite the docking area. **Express** has “sleep” mode when not in use-suggest turning unit off during long periods of non-use.

Download to computer: Download KoldLink App at www.cargodatacorp.com

Temperature records from **Express** can ALL be downloaded into a PC through a mini USB 2.0 cord (provided). Press CLEAR ALL on **Express** keypad if you do not want to save data on PC.

For more information, contact Cargo Data Corporation:
information@cargodatacorp.com or 800-338-8134.